

Fingerprint Time & Attendance

User's Manual


Contents

1. Specification	3
2. Basic Introduction of Smack Bio3000	4
1) User and Manager	4
2) Working status	4
3) Enrollment and identification	5
4) Log data	5
5) Function setting	5
3. How to use Smack Bio3000	7
1) Keyboard	7
2) Menu	7
3) Attendance identification	11
① Fingerprint identification	11
② Password verification	13
4) Enroll and Delete	14
① Enroll	14
② Enroll data deletion	24
③ All enroll data deletion	24
④ Enroll data viewing	24
5) User enrollment data modification	26
6) Enrollment based on the user database of the USB flash disk	28
7) Log data management	29
① Attendance log data	30
② Management log data	32
8) Setting	34
① System setting	34
② Log setting	38
③ Data copy	39
9) How to input fingerprint	41

1. Specification

Item		Value
CPU		ARM9 Core Samsung S3C2410 200MHz
Match speed		≤ 1 Sec (In case of 5000fp enrollment)
FAR		0.0001%
FRR		0.01%
Fingerprints Capacity		5000
Manager Count		10
ALog Count		30,000
MLog Count		1,000
Fingerprint input times for enrollment		3 times
Enroll speed		3 Sec / person
Enroll mode		fingerprint, password, fingerprint + password
Enroll ID		1 ~ 99999
Display Language		Korean, English, Chinese
Sensor	Type	Optical sensor
	Resolution	403 dpi
	Image grasping area	20mm(W) × 18mm(H)
Communication Port		TCP/IP, USB 1.1
Communication speed		115200bps
Accuracy of RTC		±1Min/month
I/O Port		wiegang26
Display mode		240 × 320 LCD
Working Voltage		9V ± 5%
Working Current		500mA
Power consumption		< 5w
Working environment	Temperature	0℃ ~ 45℃
	Humidity	20% ~ 80%
Dimensions		101mm(W) × 120mm(L)

2. Basic Introduction of Smack Bio3000



Smack Bio3000 Module

1) User and Manager

The users of time & attendance machine can be divided into managers and common users (and common users are simply called as users).

Common users can only check in on time & attendance machine, and can not do management operations.

Managers not only check in on time & attendance machine but also have management operation authority of it.

In other words manager can enroll or delete the user's (including managers) fingerprint and password, view enroll data, view and delete Alogs and MLogs and set system information.

2) Working status

Smack Bio3000 have three working status: attendance mode, management mode and communication mode.

In attendance mode user can check in with fingerprint or password and then his attendance log data is saved.

If user checks in successfully, his ID and name is displayed on LCD.

And his attendance and leaving status is displayed on LCD as one of "Regular Attend", "Late Attend", "Early Leaving", "Regular Leaving".

In management mode management operations such as new user enroll, modification and deletion of enroll data, log data viewing and system setting can be done.

Only the manager can do management operations.

To enter into management mode from attendance mode, it needs the manager identity verification.

If no manager is enrolled in time & attendance machine, everyone can do management operations without verifying the manager's identity.

3) Enrollment and identification

Enrollment and identification of users are two most important functions of time & attendance machine.

Smack Bio 3000 has 3 enroll modes: fingerprint, password and fingerprint + password enroll.

Each mode has its own proper feature and users can select required mode.

When user starts to enroll, an enroll ID which is used in identification is allotted to him.

Enroll ID is an integer from 1 to 99999.

For password enrollment, arbitrary integer from 1000 to 99999999 can be selected as password.

4) Log data

In time & attendance machine all information concerning with operations in attendance mode and management mode are saved in its memory.

These saved data are called "log data".

There are two kinds of log data that is ALog and MLog.

ALog refers to log data concerned with verification result under attendance mode and MLog refers to management operations under management mode.

Log data are conveyed to PC management software through communication port, and saved into database for searching and statistics.

5) Function setting

In time & attendance machine, manager can make his own system setting or changing of various setting value according to his requirement.

Those functions are machine ID, display language, auto off time, system time, ALog and MLog warning values, re-verify time and so on.

Machine ID is a unique number for distinction in network.

In Smack Bio 3000 Korean, English and Chinese can be used as display language.

Once auto off time is set, it will be auto off after a certain period without any operations.

The unit of auto off time is min.

ALog and MLog warning values are set to notice that ALog or MLog count has already reached to a certain limit.

Re-verify time is to check whether users check in repeatedly in a certain period.

If user makes repeated check in during a certain period, it will be seen re-verify message.

In this case ALog data won't be saved repeatedly.

Manager can change re-verify time according to his requirement.

3. How to use Smack Bio3000

1) Keyboard

Structure of the keyboard is shown below.

7	8	9	F1
4	5	6	F2
1	2	3	F3
#	0	*	F4

Functions of keyboard are as follows:

- F1 To move into former command or increase as 1 when digit inputting
- F2 To move into next command or decrease as 1 when digit inputting
- F3 To enter into menu or play a role of backspace when digit inputting
- F4 To delete digit in menu mode
- * (OK) To confirm the current setting
- # (ESC) To cancel or to move into higher grade menu
- 0 ... 9 To input digit in menu mode

2) Menu


It is convenient to operate the fingerprint time & attendance Smack Bio3000.

Using 6 function keys and number keys manager can select menu commands and set or change various kinds of functions.


And message in LCD and beep sound will inform whether the operation is correct or not.

① Main menu


Press F3 in the keyboard, then you can see 6 main menu commands.

**② User**


Select “User” in main menu and press “*”key, then you can enter into the lower grade menu which contains following commands.

**③ Manager**

Select “Manager” in main menu commands and press “*”key, then you can enter into the lower grade menu which contains following commands.

**④ Modify**

Select “Modify” item in the main menu commands and press “*”key, then you can enter into the lower grade menu which contains following commands.




⑤ **USB Reg**

If Select “USB Reg” in the main menu commands and press “*”key, then enrollment process is proceed based on the database file in the USB flash disk.

⑥ **Log**

Select “Log” in main menu commands and press “*”key, then you can enter into the lower grade menu which contains following commands.






⑦ **Set**


Select “Set” in main menu commands and press “*”key, then you can enter into the lower grade menu which contains following commands.



Each command has its own sub-commands as follows.



⑧ Menu displaying



Menu displaying screen consists of description, commands and guide message box.

- Title bar: Higher grade menu of current menu.
- Item: Operation item to select.

If manager selects a certain command using “F1” or “F2” key and presses “*”key, then he can enter into the lower grade menu or find himself in setting status of the item.

Manager can exit from the current menu and return to the higher grade menu by pressing “#” key.

In setting status manager can change setting values using “F1”, “F2” key or number keys.


There will be a warning when manager sets an invalid value.

After changing, manager can confirm changed setting value by pressing “*”key or cancel from current menu by pressing “#”key.

Being the setting operation successful, there will be a suitable message in LCD.

The setting operation failed, there will be a warning message in LCD or a beep sound that notice failure.

- Key Help Bar: Show the help of the key, “F1”, “F2”, “F3”, “F4”, “*”, “#”. Each Key is the following.



3) Attendance identification


In this section it is described the user's identification procedure in attendance mode. In this mode user can verify his identity by 2 manners namely fingerprint identification and password verification.

① Fingerprint identification

In attendance mode the first displaying screen is as follows.



When user places his already enrolled fingerprint on the fingerprint sensor, his fingerprint pattern is displayed in LCD as shown below.



If fingerprint identification is successful, user's enrollment ID and name is displayed on the screen and beep sound which means success is emitted. At the same time, one of the messages, "Regular Attend", "Late Attend", "Early Leaving" and "Regular Leaving", is displayed on the upper part of the Key Help bar(is called "Message bar" hereafter).



At the same time beep sound which means identification success is emitted.
If fingerprint identification is failed, a message as “Again input!” is displayed in guide message box and “dung” sound is emitted.

② Password verification

User who has already enrolled his password executes password verification according to the following procedure.

First press any number key in attendance mode.

Then there will be seen the screen below.



User inputs the enrolled number (ID), for example 235 using number keys and presses “*”key.

Next he inputs the enrolled password, for example 12345 and presses “*” key.



If password verification is successful, beep sound which means success is emitted.

At this time displaying screen is same to one in fingerprint verification mode.

If password verification is failed, “dung” sound is emitted and displaying screen also turns to the first screen in attendance mode.

4) **Enroll and Delete**

In Management mode manager can do various management operations for example enrollment and deletion of users, log data management, system information setting and so on.

In this section it is described enrollment of user and managers, enroll data deletion and enroll data viewing procedure.

① **Enroll**

To enter into management mode from attendance mode, press “F3” key in the first displaying screen of attendance mode.

If any manager is not enrolled in time and attendance machine, then it is possible to enter directly into management mode but if manager is enrolled, it is required the manager identity verification.

In the case of the first use of this product, there is no enroll data and therefore any user can enter into management mode.

The manager identity verification procedure is as follows.


Press “F3”key in attendance mode.

Following screen is displayed.




Manager inputs his enrolled fingerprint or password.

If manager identity verification is successful, then beep sound which means success is emitted and the first operation screen in management mode is displayed as follows.



If manager's fingerprint verification is failed, beep sound which means failure is emitted and the screen turns to following one.




Then manager can re-input enrolled fingerprint until success.

If manager's password verification is failed, beep sound which means failure is emitted and the screen turns to the first screen in attendance mode.

Then manager can repeat above operation procedure.

– User enroll

After successful manager identity verification, select "User" item in the first screen of manager operation status and press "*"key.




Select "Enroll" item and press "*"key.



Input enroll ID, for example “235”, using number keys and press “*”key. If inputted ID is one to which a certain fingerprint or password is already enrolled, then it shows



And then ID inputting dialog is again displayed. At that time manager can input another ID. If it is unenrolled ID, then it shows




- Fingerprint

Select "Finger" item using "F1" and "F2" keys and then press "*"key.
Again select "OK" item and press "*"key.




Place a finger to enroll on the fingerprint sensor.
After placing , it shows




After taking the finger off, it shows



Users should place the same finger 3 times to enroll 1 fingerprint. After placing the finger for the third time, if enroll operation is successful, it shows



In the case of failed enroll operation it shows



The enroll operation finished, there will be an enroll start screen in LCD.


Press “*”key to continue enroll operation and press “#”key to cancel.

- Password

Select “Password”item using “F1” and “F2”keys and then press “*”key.

Again select “OK”item and press “*”key.

Input password, for example 12345 using number keys and press “*”key.




Input the same password once more for confirming and press “*”key.



If password inputting is correct, it shows




If the second inputting is different with the first, it shows



At this time manager should repeat above password enroll procedure.


- **Fingerprint + Password**
Manager can enroll both fingerprint and password into an enroll ID.
First select both "finger" and "password" items using "F1", "F2" and "*" keys in the enroll start screen.
And select "Set" and press "*" key.



Manager can enroll both fingerprint and password repeating above enroll operation procedure.

– Manager enroll

Select “Manager” item in the first screen of manager operation status and press “*”key.



Manager can do fingerprint enroll, password enroll and fingerprint + password enroll operations on managers according to the same procedure

as in the case of user.

The total number of managers is ten.

② Enroll data deletion

To delete user's enroll data, select "Delete" item in "User" menu and press "*" key. Then ID inputting dialog is displayed.


If manager inputs ID to delete and press "*" key, then fingerprint data or password data (or both) with the specified ID are deleted.

Manager's enroll data deletion is the same.

③ All enroll data deletion

To delete all enroll data, select "All Delete" item in "User" menu and press "*" key.

Then the following screen is displayed.




After pressing "*" key, all enroll data are deleted.

④ Enroll data viewing

Select "View" item in "User" menu and press "*" key.

Then following screen is displayed.



Select “NumOfData” item and press “*”key, then the number of enrolled users currently is displayed on the LCD screen.


Select “ID View” and press “*” key. Then ID inputting dialog is displayed. After inputting ID for example 10 to view, press “*”.



If manager inputs ID, for example 5, into which any data is not enrolled, it will be a following message.



To view all users' enroll data select "All View" in the former screen and press "*" key. Then it shows




In this screen manager can view contents of all users' enroll data. Manager enroll data viewing is the same.

5) User enrollment data modification

Manager can modify the rights or enrollment data of any enrolled user in the management status.

Select “Modify” key in the main menu and press “*”key, then ID input dialog box displayed, you input the ID to modify and press “*”key. Then the following screen is displayed.



① Modify rights

This is the function that makes user change into manager or manager change into user.

Select “Rights” item and press “*”key, then the following screen is displayed.




If press “*”key, then rights is changed into other rights.

If press “#”key, then modification operation is canceled.

② Modify enrolled data

This is the function that modify the enrolled user's finger data or password. Select "Data" command and press "*"key, then current ID, finger ID, Password ID is displayed. If there is no enrolled finger or password, value is -1.



If press "*"key again, modify enrolled data in the same way of the user enrollment process except the ID input process

6) Enrollment based on the user database of the USB flash disk

Manager can enroll user or manager based on the enrollment database file on the USB flash disk.

The file format must be Unicode text file (When edit and save the data file in the MS Word, you must save file with selection the "txt" and "Unicode encoding").

Data record formation must be following.

ID	Name	Manager flag(If 1, then manager, else if 0 or no, then user)
----	------	--

Data file name must be the Machine ID.txt where you are enrolling.

For example, when enroll on the machine its Machine ID 2, the filename must be 2.txt.

First, plug the usb flash disk within the data file into the USB port and select "USB Reg" and press "*"key, then the data of the first user in the data file is displayed.



If press “*”key, then enroll finger and you can cancel while doing by press “#”key.

If enrollment is finished or canceled, the next user's data is displayed and enrollment is continued.

After the enrollment of all user in the data file is finished, the result is displayed.




7) Log data management

Manager can do log data management operation such as viewing and deletion of attendance logs and management logs in management mode.

① Attendance log data

Select “Log” item in the first operation screen on management mode and press “*” key. Then it shows



Select “Attendance” and press “*” key.



If manager selects “NumOfData” item and press “*” key, then it will be seen the number of current attendance logs.

In the “ID View”, it shows the attendance logs of the inputted ID.

At this time, the manager can select the search items(date, type of attendance/ leaving) and investigates them.


First of all, select “ID View” item and press “*”key, then Input date window is displayed on the LCD.



Set the dates for searching and then press “*”key. After this, Selection window of the searching items is displayed.



After select the items for searching, select the “OK” button and press “*”key. And then the log data are displayed on the LCD screen.



Log data format is the following.

ID : Month/Day/Year Time (hh:mm) Type Result

Fp: Fingerprint authentication

Pw: Password authentication

At: Regular Attendance

Lt: Late Attendance

EL: Early Leaving

Lv: Regular Leaving

Manager can investigate the situation of the attendance and leaving about the certain ID.

“Date View” shows the log data of the all ID in the period of the set date.


“Date View” is the same to “ID View” except “ID input” process.

In “All View” manager can set only searching item(T/A item) and all log data are shown.

“Delete” process is the same to “All delete” in “User”.

② Management log data

If manager selects “Manager” and press “*” key in “Log” menu, it will be a following screen.



Select "NumOfData" and press "*" key.

Then it will be seen the number of current management logs.

In connection with the other items it is the same as the case of attendance logs.

8) Setting


Manager can set or change various items concerning with time and attendance management.

Please select “Set” item in the first operation screen on management mode and press “*” key. Then it shows



① System setting

Select “System Set” in above screen and press “*” key. Then it will be seen a following screen.



- Machine ID setting

If manager select "Machine ID" and press "*" key then it shows



Machine ID can be set from 1 to 255.

Note: Don't use the same Machine ID in the same network.

- Time setting

If manager select "Time" and press "*" key then it shows



Manager can set or change time in sequence of year, month, date, hour, minute and second by using "F1" ~ "F3" keys.

- Language Setting

Select "Language" item in "Set" menu and press "*".



Please select required item by using “F1” and “F2” keys and press “*” key.

Then all contents in LCD are displayed in selected language.

– Auto off time setting

If manager select “Auto off” and press “*” key then it shows




The unit of auto off time is “min”.

The time setting is between 1 ~ 255.

– IP address setting

If manager select “IP Address” and press “*” key then it shows



Manager can input IP address by using “F1” ~ “F3” keys.

After IP address inputting, press “*” key to save or “#” key to cancel.

- Screen saver delay time setting
Select “ScrSvr” item and press “*”key.



Delay time can be decrease or increase 20 seconds at a time by pressing “F1” or “F2” key.

Manager can save the delay time by pressing “*”key or cancel by pressing “#”key.

② Log setting

Select “Log” in “Set” menu and press “*” key. Then it will be seen a following screen.



- T/A time setting

If manager select “T/A time” and press “*” key then it shows



Manager can input T/A time by using “F1” ~ “F3” keys.

- Warning time setting

Select “Warning” in former screen and press “*” key.



- Re-verify time setting
Select “Re-verify” in former screen and press “*” key.
The unit of re-verify time is “second”.



③ Data copy

Manager can do operations such as data copying to memory, backup processing and data updating.

Please select “Data Copy” item in “Set” menu and press “*”.



After connecting flash memory to time & attendance machine, select required item and press "*" key.
Then corresponding operation will be done.


9) How to input fingerprint

It is very important to input fingerprint well when fingerprint enrollment because of so great influence of enrolled fingerprint to the convenience and security in further use.


Don't move your finger when pressing.

Please horizontally place and hold the core of your finger on the central surface of sensor with proper power.


Please take care not to make your finger stand and not to lie on finger's side.




Below some incorrect fingerprint inputting are shown.




To be one-side of sensor



To make finger stand



To lie on finger's side



To place finger too slightly